

DRIVER UTILITY POS-6920(PA-6151) v2.3

Driver CD Revision History

V2.2→v2.3

Update request by ECN 20150909000279, RB Updated info:

Due to the Realtek network card chip RTL-8119CG update rev0b to rev18 version, so the network card :

1. Windows 7 drivers from 7.069.0304.2013 updated to 7.092.0115.2015 version.
2. Windows XP drivers from 5.814.0624.2013 updated to 5.830.1204.2014 version.

v2.1→v2.2

1. Related 6510 motherboard model sets for RB version.
2. Lan and Touch EOL, updated version for RB.

Note: 6510 models continue to use the Driver for RB, RA Devices driver had to apply for RB, and includes updated LAN and Touch driver.

v2.0→v2.1

1. Add WIN7 64bit driver
2. Add Intel mini-pcie wireless driver
3. Add SII WIN7 64bit driver
4. Change ID Tech OPOS driver

v1.0→v2.0

1. Update touch screen driver for linux
2. Update user manual 2nd display assembly guide

=====  
=====

All rights reserved. Copyright 2014

=====  
=====

1. Click on the self-extracting and self-installing setup file and

answer all prompts presented.

2. You will be prompted to reboot when installation is complete.

3.The sequence of setup is Main Chip --> VGA --> LAN --> SOUND --> TOUCH

```
=====
=====
DRIVER CD CONTENT
=====
=====
DRIVER\---->>\FLASH BIOS\69200P03.bat
      |
      |
      +---->\Plaform\XP.POSReady2009 (32-bit)\Main Chip\Setup.exe (Intel
Chipset Software Installation Utility only for windows OS)
      +---->\Plaform\Win7.POSReady7(32-bit)\Main Chip\Setup.exe (Intel
Chipset Software Installation Utility only for windows OS)
      +---->\Platform\Win7.POSReady7(64-bit)\Main Chip\Setup.exe (Intel
Chipset Software Installation Utility only for windows OS)
      |
      |
      +---->\Plaform\XP.POSReady2009 (32-bit)\VGA\Setup.exe(WINXP ,POS
Ready 2009 DRIVER)
      +---->\Plaform\Win7.POSReady7(32-bit)\VGA\Setup.exe (WIN7 32bit
DRIVER)
      +---->\Platform\Win7.POSReady7(64-bit)\VGA\Setup.exe(WIN7 64bit
DRIVER)
      |
      |
      +---->\Plaform\XP.POSReady2009 (32-bit)\LAN\RB\setup.exe
(WINXP ,POS Ready 2009 DRIVER)
      +---->\Plaform\Win7.POSReady7(32-bit)\LAN\RB\Setup.exe (WIN7 32bit
DRIVER)
      +---->\Plaform\Win7.POSReady(64bit)\LAN\RB\Setup.exe (WIN7 64bit
DRIVER)
      |
      |
      +---->\Plaform\XP.POSReady2009 (32-bit)\Sound\WDM_R266.exe
```

(WINXP ,POS Ready 2009 DRIVER)

+---->\Plaform\Win7.POSReady7(32-bit)\Sound\Vista\_Win7\_R266.exe

(WINVISTA/7 32bit and 64bit DRIVER)

+---->\Plaform\Win7.POSReady(64bit)\Sound\64bit\_Vista\_Win7\_R270.exe(WIN7  
64bit DRIVER)

|  
|

+---->\Device\Touch Screen\Setup.exe (WINXP ,POS Ready 2009,  
WIN\_7\_32\_64bit DRIVER)

|  
|

+---->\Device\Embedded Finger Printer\DigitalPersonal\ (Option)

|  
|

+---->\Device\Embedded MSR\ID Tech MSR Driver and Utility\ (ID Tech  
MSR and Sysking MSR , demo AP , OPOS Driver) (Option)

|  
|

+---->\Device\RFID Module\GIGA-TMS\ (DF5 MIFARE® /DESFire® OEM  
Read/Write Module\Driver) (Option)

|  
|

+---->\Device\VFD\LABAU\VFDPOSSetup5.5\ (demp AP ,OPOS Driver)  
(Option)

|  
|

+---->\Device\Wifi Module\Intel\ ( WindowsXP,POS Ready 2009,  
WIN\_7\_32\_64bit) (Option)

|  
|

+---->\Device\Embedded Printer\ (Labau and SII Printer Driver,support  
32bit OS)

API Package\---+---->\DEMO PROJECT\

```
|
|
+---->\ProxAPI standard\
|
|
+---->\Document\
```

MANUAL\AdbRdr930\_en\_US.exe (PDF File reader)

```
=====
=====
```

## 1. System BIOS Update

Users of AMI BIOS can use the program "AFU.bat" contained in CD-ROM for BIOS update.

- a. This is found in DVD:\Flash\AFU.bat
- b. For RA MB-->afudos 69200P01.ROM /p /b /n /c /x
- c. For RB MB-->afudos 69200P03.ROM /p /b /n /c /x

### BIOS FLASH SETUP:

a. Prepare a bootable flash drive and include DOS files: AFUDOS.EXE, AFU.BAT and "BIOS ROM file

(ex.6920XXXX.ROM)" (\*the flash drive need 2MB free space. )

b. Use flash drive to boot, then type "AFU 69200P03.ROM" and press enter to automatically flash BIOS.

(ex. C:\>afu 69200P03.ROM <enter>)

2. The system has LAN function (Realtek RTL8111DL) that can support various network adapters. The content of the LAN driver is found as follows:

a. Windows XP\_POS Ready2009 /Windows 7\_32\_64bit

3. The Realtek ALC888 HD Audio codec sound function enhanced in this system fully compatible with

Windows XP, Windows Vista you will find the content of the Sound driver.

a. Windows XP\_POS Ready2009 /Windows 7\_32\_64bit

4. The Main Chip directory is contained in DVD-ROM for INTEL D525 Driver

a. Windows XP\_POS Ready2009 /Windows 7\_32\_64bit

5. The VGA interface (Intel(R) Graphics Media Accelerator 3150 ) is embedded with our system to support

CRT display, Panel Link (optional) and TV-Out Encoder (optional). The following illustration briefly shows

you the content of VGA driver in sub-directory \VGA\

a. Windows XP\_POS Ready2009 /Windows 7\_32\_64bit

\*\*\*\* Third party trademarks or brand names are the property of their owners.\*\*\*\*